Rotating 6 DIRECTIONAL ROTATION Tires

>> A Crusingator Document <<

Move > 1 to 3, 3 to 5, 5 to 1 Move > 2 to 6, 6 to 4, 4 to 2

